

Seismic Attributes and Synthetic logs

- Synthetic logs (impedance inversion)
- Instantaneous attributes
- Reading:
 - › Yilmaz, Chapter 8.5, 8.6

Synthetic logs

- The usual use of seismic records is to observe the continuity of the structure between boreholes
 - ◆ This is still mostly qualitative
- **Idea:** invert the equation for reflection coefficient:

$$R_i = \frac{Z_{i+1} - Z_i}{Z_{i+1} + Z_i} = \frac{Z_{i+1}/Z_i - 1}{Z_{i+1}/Z_i + 1}$$

to transform seismic traces into “synthetic logs”:

$$Z_{i+1} = Z_i \frac{1 + R_i}{1 - R_i} \quad \text{for impedance}$$

$$V_{i+1} = V_i \frac{1 + R_i}{1 - R_i} \quad \text{for velocity}$$

(assuming density constant)


Synthetic logs

- Reflection records contain no near-zero frequencies, and so *recursive* calculation for Z or V:


$$Z_{i+1} = Z_i \frac{1 + R_i}{1 - R_i}$$

suffers from low-frequency *drift* of amplitudes


- This needs to be corrected by calibration using smoothed Z or V from well logs



Synthetic logs






CMP stack containing a bright spot



Synthetic velocity log inverted from this section

From Yilmaz, 1987

Accurate synthetic logs can be produced by calibrating seismic-impedance sections with complete well-log spectra



Impedance section having amplitude spectra of the log above

Attributes

- Generally, term *attributes* usually refers to quantities that are:
 - ◆ Derived quantitatively from data on sample-by sample basis
 - ◆ Often have unclear physical meaning
 - ◆ Nevertheless, useful to highlight certain aspects of the data
- *Instantaneous* attributes are usually single-trace attributes based on the concept of “*complex trace*”, or “*analytic signal*”
 - ◆ This concept is based on *Hilbert transform* of the signal

Hilbert transform

- Hilbert transform transforms a time-domain signal $u(t)$ into another $u_H(t)$:

$$u_H(t) = \frac{1}{\pi t} * u(t)$$

$$u_H(t) = \frac{1}{\pi} \int \frac{u(\tau)}{(t-\tau)} d\tau$$

- In frequency domain:

$$u_H(\omega) = -i \operatorname{sgn}(\omega) u(\omega)$$

- Most important examples:

$$[\sin(\omega t)]_H = -i \cos(\omega t)$$

$$[\cos(\omega t)]_H = i \sin(\omega t)$$

$$[e^{i\omega t}]_H = -i e^{i\omega t}$$

Complex trace

- Analytic (complex-valued) signal is defined as:

$$u_A(t) = u(t) + iu_H(t)$$

- It combines the original and 90-degree shifted signal at each frequency

- so that:

$$u(t) = \text{Re}[u_A(t)]$$

- Decomposition to complex amplitude and phase:

$$u_A(t) = A(t) e^{i\phi(t)}$$

Slowly varying,
Instantaneous amplitude



Quickly varying,
Instantaneous phase

Instantaneous frequency



- “Instantaneous frequency” is the rate of temporal change in ϕ :

$$\omega(t) = \frac{d\phi(t)}{dt}$$



- Note that the true Fourier frequency ω cannot be time-dependent
- Instantaneous frequency is often highly variable in seismic sections, and so it is often **smoothed**
- Areas of low instantaneous frequency are often interpreted as caused by **attenuation**
 - Although the above is hardly true, low inst. frequency has helped to identify some condensate reservoirs




Instant.
amplitude



Instant.
phase



Instant.
frequency



Smoothed
instant.
frequency